



### SPECIFICATION

Theft Resistant Spindle shall be fabricated of hi-impact resistant ABS plastic. Unit shall accommodate a standard spring-tension plastic roller (JDM Model No. R-003, supplied separately) to provide increased vandal resistance. Unit shall fit into all standard holders that receive R-003 and shall hold standard roll tissue with 35mm ID core. R-009 can be used in conjunction with items 7305, 7305-2, 7402, 74022 and 0697-GAL.

### INSTALLATION

Insert smaller diameter end (inside telescope) spring loaded roller from dispenser inside screw cap. Screw cap onto threaded body to contain larger (outside telescope) diameter end until R-009 length is 1.6mm less than spacing between dispenser posts (supplied separately). Load R-009 with toilet paper and insert into dispenser posts.

### OPERATION

Paper core must be ripped off to remove R-009 after roll is exhausted. Grasp inside roller through opposing windows and retract pivot end from holder socket.

**Theft Resistant Spindle** shall be Model No. R-009 as supplied by JD MacDonald.

